

Northbridge Heatsink

Installation with Thermal Adhesive Tape

First stick the double-sided thermal adhesive tape on to the base of the heatsink. Then gently place the heatsink on the Northbridge chipset.

Installation with the Pushpin

- Attach the spring and the pushpin to the link
- Clean the surface of the heatsink, and spread the thermal grease evenly over the base of the heatsink
- Insert the link assembly into the groove on the heatsink
- Align the pushpins on the link assembly with the holes on the motherboard, and ensure the pushpins are firmly in place.

Removal of the Northbridge Heatsink

At the back of the mainboard, squeeze in the pushpin to remove the Northbridge heatsink.



CAUTION:

1. Thermal adhesive tape can not be reused after removal.
2. XILENCE is not responsible for damages to the system caused by overclocking.

Package Contents:

- Heatsink
- High-density, ceramic-based thermal grease
- High performance 2-sided thermal adhesive tape, Spring, Pushpin and link